

# Chemical Response in Emergency Response Situations

Rick Patterson

&

Shane Waskom

Teamsters Local Union 519

Knoxville, TN

# Information Sources

- SDS
- ERG'S
- Internet/cell phones
- Labels
- Placards
- Containers

# Information Breakdown

- Incomplete/Incorrect Information
- Insufficient Training
- Lack of Communication
- Synergistic Effects


# Case Study: Fly Ash

- Definition/Source
- Composition
  - Coal Type
  - Combustion Process

# Fly Ash in Occupational Health

- Unique Hazards
  - Multiple Components
  - Variable Concentrations
- Storage
  - Capacity
  - Releases

# Percentage of Permissible Exposure Limit



# Formula

- Formula:
  - C=Concentration
  - L=Limit
  - $C_1/L_1 + C_2/L_2 + C_n/L_n = \text{Combined Limit}$
- Combined Limit > 1 means PPE is required.
- Limitations
  - Target Organs
  - Health Effects
  - State of Matter

# Formula Examples

- $C_1$  (Mercury)
  - Concentration = .076 mg/m<sup>3</sup>
  - Limit = .1 mg/m<sup>3</sup>
- $C_2$  (Copper)
  - Concentration = .69 mg/m<sup>3</sup>
  - Limit = 1 mg/m<sup>3</sup>



# Formula Walkthrough


$$C_1/L_1 + C_2/L_2 = \text{Combined TWA \%}$$

$$.076/.1 + .69/1 = \text{Combined TWA \%}$$


$$.76 + .69 = \text{Combined TWA \%}$$

$$1.45 = \text{Combined TWA \%}$$


# Daily Observed Concentration of Mercury and 8 Hour TWA Percentages



# Daily Observed Concentration of Mercury and Copper and 8 Hour TWA Percentages



# TWA's for Mercury and Copper



# TVA Kington Coal Ash spill

